

## X-360 Body Installation Instructions

### Tools Needed:

Phillips Screwdriver  
10mm Wrench or Socket  
12" Crescent Wrench or Channel Lock Pliers  
1 Small Straight Jewelers Screwdriver  
1 Roll Masking Tape  
1/4" Wrench or Small Crescent Wrench  
Ink Pen or Pencil

1. Loosen and remove the clamps for the seat and the handlebars. Remove the seat, seat pole, and handlebars.
2. Using the large crescent wrench or channel locks, remove both of the large nuts directly below the handlebars.
3. Tear off two 1" pieces of masking tape and label with #1 or the letter A. Open battery compartment and find the white plug. Put one piece of the tape labeled #1, on each side of the white plug. Unplug that plug. Repeat labeling of the wires until all of the white plugs are labeled and unplugged. This will ensure that all wiring will get plugged back in correctly.
4. Loosen the gold nut beside the back wheel where the brake cable runs through and remove the brake cable.
5. Pull all wires and brake cable up through the hole in the body by the handlebars. If necessary, pull one white plug at a time through the hole in the body by the handlebars.

\*\* Note: Do NOT pull on snagged wires as this may cause broken wires!!

6. When all the wires and brake cable are removed, tear off the decals on both foot rests. Use the Phillips screwdriver and 10mm Wrench to loosen and remove the body bolts.
7. Remove the Trunk Rack.
8. Lift the body off of the black frame. You may have to twist and work it a little to get the rubber grommet in the front to come off.

## **X-360 Body Installation Instructions – continued**

9. With the Jewelers screwdriver, remove the wires and gold prongs from the white plugs. Do this by pushing over on the tab side of the gold prong with the screwdriver and pull on the wire (don't pull too hard). If it won't come loose, just keep trying, it will.
  
10. Loosen and remove the nuts on the back of the sidelights and the rear light. Pry them off the body. Pull the wires out of the holes. Re-install the lights on the new body. Go ahead and put the white plugs back on the wires after the lights are on the body.
  
11. Re-install the body by reversing all of these steps.
  
12. When you re-install the brake cable, pull the bracket toward the front of the scooter and pull the brake cable to the back of the scooter and tighten nut.

Enjoy your scooter!!

Should you need technical assistance, please go to  
[www.x-tremescooters.com/support/](http://www.x-tremescooters.com/support/)